









The milling cutter that is used at cutting off workpiece is to curium a milling cutter. To increase the rigidity of arbor, curium piece milling cutter should stand by main shaft as far as possible or suspension is installed; Do not install key between milling cutter and arbor, the attrition force between two side end panel drives support arbor gasket and milling cutter milling cutter rotates, key can be held inside the gasket that stands by feed nut, become loose with preventing milling cutter effectively; The radial tooth should assure after milling cutter is installed and axial circle are jumpy do not stipulate the value just can be used more than.



